

HOSE COUPLING EXPANDING MACHINE (B-1600) PARTS LIST

B-1600	Expanding Machine	B-1658	2-1/2" Plate
B-1605	5" Hydraulic Cylinder	B-1659	3" Mandrel
B-1102	Motor & Hyd. Power Pack	B-1660	3" Plate
B-1104	Table	B-1661	3-1/2" Mandrel
B-1108	Long Hose	B-1662	4" Mandrel
B-1109	Short Hose	B-1670	4" Plate
B-1619	Threaded Rod (4 pcs-16")	B-1691	4-1/4" Mandrel
B-1620	Threaded Rod (4 pcs-23")	B-1692	4-1/2" Mandrel
B-1621	Nuts (16 pcs)	B-1671	5" Mandrel
B-1602	End Plate	B-1672	5" Plate
B-1623	Adapter	B-1191	6" Mandrel
B-1604	Extension Adapter	B-1667	1-1/2" Raised End Plate
B-1601	Cylinder Adapter Plate	B-1663	2" Raised End Plate
B-1603	Mounting Block	B-1664	2-1/2" Raised End Plate
B-1606	Large Nut	B-1665	3" Raised End Plate
B-1650	Mandrel & Plate Box	B-1666	4" Raised End Plate
B-1151	1-1/4" Mandrel	B-1180	3/4" Mandrel
B-1652	1-1/4" Plate	B-1681	3/4" Back Plate
B-1153	1-1/2" Mandrel	B-1182	3/4" Adapter
B-1654	1-1/2" Plate	B-1186	1" Mandrel
B-1655	2" Mandrel	B-1687	1" Back Plate
B-1656	2" Plate	B-1188	1" Adapter
B-1657	2-1/2" Mandrel		